





\*30.5cm プレート 4675L/58505A ¥12,000 D:303・H:25



\*27cm プレート 4675K/97220 ¥4,200 D:270·H:22



\*21cm プレート 4675K/97211 ¥3,000 D:212·H:19



\*16.5cm プレート 4675K/97212 ¥2,250 D:167·H:17



\*26cm ディーププレート 4675K/97290S ¥5,300 D:262·H:42 C: 約805



\*21.5cm ディーププレート 4675K/97207 ¥3,500 D:214·H:38 C:約300



ティーポット (大) 4675K/50023A ¥13,500 D:126·T.L.:203 H:142·C: 約825



ティーポット (小) 4675K/50024A ¥10,000 D:103·T.L.:169 H:116·C: 約445



シュガー 4675K/50061A ¥6,800 D:91·H:86 C: 約210



クリーマー 4675K/50067A ¥5,400 D:71·T.L.:84·H:71 C: 約180



ティー・コーヒーカップ 4675K/97287C ¥2,600 D:93・T.L.:116·H:60 C: 約205 ソーサー 4675K/97217S ¥1,800 ¥1,800 D:151·H:21



\*デミタスカップ 4675K/97294C ¥2,400 D:56·T.L.:77·H:56 C:約90 \*デミタスソーサー 4675K/97294S ¥1,700 D:121·H:18



\*スープカップカバー 4675K/59770CA ¥2,600 D:122:H:35 \*スープカップ 4675K/59770BA ¥2,600 D:118:H:62-C: 約265 \*ソーサー 4675K/97255S ¥1,800 D:166:H:22 D:166·H:22