



10-67-1-27431001 ¥3,350
31cmプラター
31.8×22.8×4.4



10-67-2-27429001 ¥2,680
29cmプラター
29.3×20.9×4.2



10-67-3-27426001 ¥2,210
26cmプラター
26×18.9×3.6



10-67-4-27423001 ¥1,600
23cmプラター
23.9×17.1×3.3



10-67-5-27420001 ¥1,420
20cmプラター
20.1×13.3×2.6



10-67-6-27417001 ¥1,170
17cmプラター
17.1×11.3×2.8



10-67-7-77518001 ¥2,100
MSペーカー
26.3×18.5×6.1



エスプレッソ碗皿 **¥700**
10-67-8-31102001 ¥370
碗 6.3×5.2・100cc
10-67-9-31220001 ¥330
受皿S 13.2×2



HB-Tコーヒ一碗皿 **¥660**
10-67-10-31111001 ¥400
碗 7.4×6.5・180cc
10-67-11-43200001 ¥260
受皿T 13.1×2.2



HB-Rコーヒ一碗皿 **¥680**
10-67-12-31112001 ¥400
碗 7.4×6.5・180cc
10-67-13-00160001 ¥280
受皿R 15.6×2.1



コーヒ一碗皿 **¥730**
10-67-14-31100001 ¥400
碗 7.2×6.8・170cc
10-67-15-31210001 ¥330
受皿 14.8×2



兼用碗皿 **¥760**
10-67-16-31101001 ¥430
碗 8.3×5.5・170cc
10-67-17-31210001 ¥330
受皿 14.8×2



カプチーノ碗皿 **¥780**
10-67-18-31104001 ¥450
碗 9.3×6・220cc
10-67-19-31210001 ¥330
受皿 14.8×2



アメリカン碗皿 **¥760**
10-67-20-31103001 ¥430
碗 7.8×7.3・220cc
10-67-21-31210001 ¥330
受皿 14.8×2



スープ碗皿 **¥810**
10-67-22-31470001 ¥480
碗 10.2×5.8・260cc
10-67-23-31210001 ¥330
受皿 14.8×2



スタックエスプレッソ碗皿 **¥700**
10-67-24-31107001 ¥370
碗 6.3×5.2・100cc
10-67-25-31220001 ¥330
受皿S 13.2×2



スタックコーヒ一碗皿 **¥730**
10-67-26-31105001 ¥400
碗 7×6.8・180cc
10-67-27-31210001 ¥330
受皿 14.8×2



スタック兼用碗皿 **¥760**
10-67-28-31106001 ¥430
碗 8.2×5.8・200cc
10-67-29-31210001 ¥330
受皿 14.8×2



スタックカプチーノ碗皿 **¥780**
10-67-30-31109001 ¥450
碗 9×5.8・240cc
10-67-31-31210001 ¥330
受皿 14.8×2



スタックアメリカン碗皿 **¥760**
10-67-32-31108001 ¥430
碗 7.7×7.2・230cc
10-67-33-31210001 ¥330
受皿 14.8×2



スタックスープ碗皿 **¥810**
10-67-34-31471001 ¥480
碗 10×5.4・280cc
10-67-35-31210001 ¥330
受皿 14.8×2



10-67-36-31501001 ¥550
ティーバクトレ
11.3×8.5×1.9



10-67-37-31502001 ¥430
プチムーンディッシュ
8.9×6.1×2.2



10-67-38-31503001 ¥440
プチスターディッシュ
9×8.5×2.2



10-67-39-31504001 ¥410
ハート小皿
9×9×1.9



10-67-40-75505001 ¥340
精円ミニボール
9.2×5.8×3.1



10-67-41-39505001 ¥380
ウェーブミニボール
9.7×6.4×2.9



10-67-42-39062001 ¥400
強化コーヒースプーン
12.3×2.2 1.5cc