



10-131-1-50521001 ¥3,500
26cm丸仕切皿 26×2.5




10-131-2-50522001 ¥2,250
21cm丸仕切皿 21.5×2.6

カップスペース6cm



10-131-3-50516001 ¥5,600
29cm仕切皿 29×19.6×2.4



10-131-4-49370001 ¥2,150
18cm長角皿 18.3×12.5×2.6



¥1,650
10-131-5-49010001 ¥890
ライス碗 (大) 14.8×7.1・400cc
10-131-6-49070001 ¥760
蓋 (大) 13.1×3.6



¥1,600
10-131-7-49020001 ¥870
ライス碗 (中) 13.4×7・300cc
10-131-8-49080001 ¥730
蓋 (中) 12.2×3.3



¥1,490
10-131-9-49030001 ¥770
ライス碗 (小) 12.2×5.9・200cc
10-131-10-49090001 ¥720
蓋 (小) 10.9×3.3



¥1,650
10-131-11-49040001 ¥890
多用碗 (大) 14.8×6.1・300cc
10-131-12-49070001 ¥760
蓋 (大) 13.1×3.6



¥1,600
10-131-13-49050001 ¥870
多用碗 (中) 13.6×6.1・300cc
10-131-14-49080001 ¥730
蓋 (中) 12.2×3.3



¥1,490
10-131-15-49060001 ¥770
多用碗 (小) 12.2×5.9・250cc
10-131-16-49090001 ¥720
蓋 (小) 10.9×3.3



¥1,150
10-131-17-49100001
¥670
丸深鉢 10.6×6.7・260cc
10-131-18-49171001
¥480
かぶせ蓋 (大) 11×2



¥1,080
10-131-19-49110001
¥600
丸小鉢 10.6×6・220cc
10-131-20-49171001
¥480
かぶせ蓋 (大) 11×2



¥1,640
10-131-21-49140001
¥680
茶碗蒸 7.4×6.6・170cc
10-131-22-49172001
¥480 かぶせ蓋 (小) 8.4×1.7
10-131-23-50604001
¥480 受皿 10×2