



10-136-1-49210603
¥930
11cm菊型深鉢 11×5.5・320cc

10-136-2-49220603
¥860
11cm菊型浅鉢 10.9×3.3

10-136-3-49180603
¥1,190
12cm六山鉢 12×5.8・300cc



10-136-4-49190603
¥1,080
11cm六山鉢 11.1×4.8・200cc

10-136-5-49420603
¥870
長湯呑 6.3×7.5・160cc

10-136-6-50481603
¥900
反湯呑 9.3×5.8・200cc



10-136-7-50505603
¥1,020
13cm耳付小鉢 12.8×11.3×4.2

10-136-8-48130603
¥1,050
スタック碗
8.3×6・200cc

10-136-9-51130603
¥1,150
マグカップ 7.3×7.3・200cc



10-136-10-51139603
¥1,150
スタックカップ 7.3×7.6・200cc

10-136-11-48110603
¥1,200
スタック兼用碗 8.3×6・200cc

10-136-12-48120603
¥1,210
スタック両手碗 8.3×6・200cc

10-136-13-50101603
¥1,270
オープンハンドル 8.6×6.6・190cc



¥1,790
10-136-14-49100603
¥1,070
丸深鉢 10.6×6.7・260cc
10-136-15-49171603
¥720
かぶせ蓋 (大) 11×2

¥1,670
10-136-16-49110603
¥950
丸小鉢 10.6×6・220cc
10-136-17-49171603
¥720
かぶせ蓋 (大) 11×2

¥2,300
10-136-18-49140603
¥970 茶碗蒸 7.4×6.6・170cc
10-136-19-49172603
¥650 かぶせ蓋 (小) 8.4×1.7
10-136-20-50604603
¥680 受皿 10×2

10-136-21-49240603
¥1,440
10cm角鉢 9.8×3.6

10-136-22-49230603
¥1,600
9cm隅切角小鉢 9.4×4.9



¥2,420
10-136-23-49010603
¥1,370
ライス碗 (大)
14.8×9.8・400cc
10-136-24-49070603
¥1,050 蓋 (大)
13.1×3.6

¥2,200
10-136-25-49020603
¥1,200
ライス碗 (中)
13.4×7・300cc
10-136-26-49080603
¥1,000 蓋 (中)
12.2×3.3

¥2,100
10-136-27-49030603
¥1,200
ライス碗 (小)
12.2×5.9・200cc
10-136-28-49090603
¥900 蓋 (小)
10.9×3.3

¥2,420
10-136-29-49040603
¥1,370
多用碗 (大)
14.8×6.1・300cc
10-136-30-49070603
¥1,050 蓋 (大)
13.1×3.6

¥2,200
10-136-31-49050603
¥1,200
多用碗 (中)
13.6×6.1・300cc
10-136-32-49080603
¥1,000 蓋 (中)
12.2×3.3

¥2,100
10-136-33-49060603
¥1,200
多用碗 (小)
12.2×5.9・250cc
10-136-34-49090603
¥900 蓋 (小)
10.9×3.3

和食器

軽量強化 唐辛子
イングレース