



**10-161-1**-26624001 **¥2,760**  
24cmラウンドプレート  
24.3×1.9



**10-161-2**-26620001 **¥1,640**  
20cmラウンドプレート  
20.3×1.9




**10-161-3**-26616001 **¥940**  
16cmラウンドプレート  
16.3×1.9



**10-161-4**-26612001 **¥710**  
12cmラウンドプレート  
12.1×1.9



**10-161-5**-26725001 **¥3,200**  
カレントスクエア  
25.5×25.5



**10-161-6**-26719001 **¥1,890**  
ミラノスクエア  
19.5×19.5



**10-161-7**-26820001 **¥1,340**  
レクタングルS  
19.5×11.9



**10-161-8**-26810001 **¥2,590**  
レクタングルL  
32.5×12



**10-161-9**-26830001 **¥1,760**  
3リングプレート  
25.2×12



**10-161-10**-26840001 **¥1,130**  
2リングプレート  
18.5×12



**10-161-11**-60616001 **¥440**  
13cmスタッカー浅  
13.1×3.5



**10-161-12**-60611001 **¥390**  
11cmスタッカー浅  
11.5×2.6



**10-161-13**-28432001 **¥2,450**  
32cmプラター 32×20.5×2.6



**10-161-14**-28430001 **¥2,100**  
30cmプラター 29.8×19.2×3.1



**10-161-15**-28426001 **¥1,900**  
26cmプラター 26.2×17×2.8



**10-161-16**-28424001 **¥1,450**  
24cmプラター 23.7×15.2×2.5



**10-161-17**-28421001 **¥1,250**  
21cmプラター 21.3×13.8×2.3



**10-161-18**-28417001 **¥1,050**  
17cmプラター 17×11×1.8



**10-161-19**-15310001 **¥380**  
10cm二分皿 10.2×2



**10-161-20**-15412001 **¥410**  
12cm三分皿 12×2.1



**10-161-21**-21038001 **¥340**  
7cm正角皿 7×7×3.2



**10-161-22**-21022001 **¥530**  
14cm二連皿  
13.7×7×3.2



**10-161-23**-21023001 **¥690**  
20cm三連皿  
20×7×3.2

和食器

雪白白