



10-173-1-41190073 ¥990
24cm深皿 粉引 24.1×4.7



10-173-2-41180073 ¥670
21cm深皿 粉引 21.3×4.2



10-173-3-41010073 ¥430
14cm深皿 粉引 14.6×3.6



10-173-4-41011073 ¥410
13cm深皿 粉引 12.8×3.2



10-173-5-41013073 ¥400
11cm深皿 粉引 11.1×2.7



10-173-6-41012073 ¥380
10cm深皿 粉引 9.8×2.7



10-173-7-88363073 ¥1,330
切立19cm深丼 粉引 18.8×10.2-1,200cc



10-173-8-88360073 ¥1,160
切立18cm深丼 粉引 18×9.2-990cc

和食器

綿雪
粉引



10-173-9-88545073 ¥540
丸14cm碗 粉引 14.2×6.5-490cc



10-173-10-88542073 ¥510
丸13cm碗 粉引 13×6.2-390cc



10-173-11-88583073 ¥480
丸12cm碗 粉引 12.1×5.9-350cc



10-173-12-76341073 ¥420
9cm丸鉢 粉引 9.1×3.9-150cc



10-173-13-44415073 ¥640
切立15cmライス碗 粉引
15.1×7.2-490cc



10-173-14-44414073 ¥580
切立14cmライス碗 粉引
14×6.6-390cc



10-173-15-44413073 ¥530
切立13cmライス碗 粉引
13.1×6-300cc



10-173-16-21038073 ¥380
7cm正角皿 粉引 7×7×3.2



10-173-17-21022073 ¥580
14cm二連皿 粉引 13.7×7×3.2



10-173-18-21023073 ¥750
20cm三連皿 粉引 20×7×3.2



10-173-19-76010073 ¥530
13cm呑水 粉引 13.2×12.5×4.4

